









FENIX II Series User Manual




FENIX II Series Accessories




for Intel		for AMD	
 x1 Intel Backplate	 x1 Intel Bracket	 x1 Intel 20XX Bracket	 x1 AMD Bracket
for Intel & AMD			
 x8 (240) x12 (360) Case Screws	 x4 Bracket Screws	 x1 Thermal Paste	 x1 Mini ARGB LED Controller

Intel
(LGA 1851/1700/1200/115X/1366)



Step.1



Step.2




Step.3




Intel
(LGA 20XX)


Step.1



Step.2




Step.3




AMD (LGA AM5/AM4/AM3)


Step.1




Step.2




Step.3



Step.4




Connect Cables



Mini ARGB LED Controller

Please Connect the 3Pin ARGB Connector to Mini ARGB LED Controller, Plug and Play.



M

Multiple Lighting Effect Mode

Click M Button to Switch Different LED Lighting Effects (9 Lighting Effects)

M > **S**

LED Speed Adjustment

Click M button to Enter Multiple Lighting Effect Mode
Click S Button to Change LED Speed (5 LED Speeds Available)

OFF **S** > **C** or **M**
2 SEC

LED On/Off

Click S Button and Hold More than 2 Seconds for LED Off
Click M or C Button for LED On

C

LED Single Color Mode

Click C Button to Switch Different LED Single Color (7 Colors Available)

C > **S**

LED Brightness Adjustment

Click C Button to Enter LED Single Color Mode
Click S Button to Adjust LED Brightness (4 Brightness Modes)

